

Introduction of Rocker module

1. Working principle


The rocker module can be regarded as a potentiometer with two channels, which can output the analog values of the X and Y axes. When moving to the left, the smaller the X value of the output. When moving to the right, the larger the X value of the output. When moving to the up, the larger the Y value of the output. When moving to the down, the smaller the Y value of the output.


The output analog range of the X and Y axes is from 0 to 1023.

2. Practical application

- 2.1 Game machine rocker control.
- 2.2 Remote control car control direction.

3. About module





- 3.1 Rocker module possess 4 Alligator clip port, Corresponding to GND, VCC, Y and X. The X and Y pins are the signal output pins of the rocker module.
- 3.2 4 pin female socket are reserved, which can be used after welding.
- 3.3 PH2.0 cable interface.

The default output has both X and Y values of 512.

When moving to the left, the smaller the X value of the output. When moving to the right, the larger the X value of the output.

When moving to the up,the larger the Y value of the output. When moving to the down,the smaller the Y value of the output.

Working Voltage: 3.3V/5V